

1



QUICK START GUIDE

SECOWEB-XL™



Thank you for purchasing Secoweb-XL. Secoweb-XL is a Microsoft Excel based application that monitors ECOM controllers. This guide describes how to configure Secoweb-XL and start using it. Any time you work with printed materials, consult our website to ensure you have the most recent version of those documents.

TIECHE Inc.

950 Enchanted Way, Suite 102
Simi Valley, CA 93065
Phone: +(888) 574 7330 Fax: +(805) 456 7767
Email: info@tiechesystems.com
Website: www.tiecheusa.com

TIECHE Inc. All rights reserved. ECOM NANO is a registered trademark of TIECHE Engineered Systems. The products sold by TIECHE Inc., 950 Enchanted Way, Suite 102, Simi Valley, CA 93065 are subject to the limited warranty, limited liability, and other terms and conditions of sale set forth at <http://www.tiecheusa.com>

2

PREREQUISITE, INSTALLATION AND CONFIGURATION

PREREQUISITE

Microsoft .net framework 4.0 or above.
Windows 7 or above.
Microsoft Excel.

INSTALLATION

Copy the Secoweb-XL.exe  file to your PC. Double click the file to execute the Secoweb-XL application.

CONFIGURATION



- Add controller



- Remove controller



- Reorder (Up)



- Reorder (Down)



- Restore



- Excel – Narrow



- Excel – Wide



- Close

3

Click  to define the controller to access.

Unknown	Name :	SWITCH ROOM	Add
	URL :	https://192.168.1.17/cgi-bin/ECOM.xml	
	Sampling Rate :	15 seconds	

Enter controller name.

Enter controller XML url. ECOM controller XML comes in the following format.

ECOM NANO – <https://<IPv4/IPv6 Address>/cgi-bin/ECOM.xml>

ECOM MICRO – <http://<IPv4/IPv6 Address>/cgi-bin/ECOM.xml>

Select Sampling Rate – 15; 30; 300; 600; 1800 seconds.

Click  to add controller to the list.

Online	Name :	ECOM MICRO
	URL :	http://192.168.1.5/cgi-bin/ECOM.xml
	Sampling Rate :	15 (seconds)
Offline	Name :	ECOM NANO
	URL :	https://192.168.1.72/cgi-bin/ECOM.xml
	Sampling Rate :	15 (seconds)

Once connected the controller shows **Online**, otherwise it shows **Offline**.

To remove a controller from the list, select the controller and click  to remove it from the list.

Use   to reorder the controller list.

Every time you run Secoweb-XL, it opens fresh without any previously added configuration. Click  to restore it.

4

Click  to open Microsoft Excel in narrow mode and load controller data to spreadsheet. The values/state are updated dynamically based on the sampling time specified. If there is a change in value or state while dynamically loading data, the application will display the value/state in **bold**. All Excel functions can be performed using the dynamic values. The Excel spreadsheet can be saved to your PC. Once the Secoweb-XL application is closed, the Excel spreadsheet retains the latest values.

JECOWEB-XL									
[https://www.jecoweb-xl.com/]									
Site Name:		JECOWEB-XL		Site URL:		https://www.jecoweb-xl.com/		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
JECOWEB-XL									
Site Name:		JECOWEB-XL		Site URL:		https://www.jecoweb-xl.com/		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1		Site IP:	
Site IP:		192.168.1.1		Site IP:		192.168.1.1			